

Operating and mounting manual Safety shut off valve pneumatic valve EPVF-R

Contents

- 1.0 General Remarks**
 - 1.1 Valve data
 - 1.2 Application
- 2.0 Danger Notices**
 - 2.1 Safety terms
 - 2.2 Safety notice
 - 2.3 Qualified staff
 - 2.4 Unauthorized modification and spare part production
 - 2.5 Unauthorized operation
 - 2.6 Safety information for the use in explosion-prone areas guideline 2014/34/EU
 - 2.7 Safety information regarding guideline 2014/68/EU attachment I
- 3.0 Handling**
 - 3.1 Transport
 - 3.2 Storage
 - 3.3 Handling before mounting
- 4.0 Product Description**
 - 4.1 Function
 - 4.2 Technical data
 - 4.3 Marking
- 5.0 Installation**
 - 5.1 Warning of dangers during installation, operation and maintenance
 - 5.2 Installation
- 6.0 Operation**
 - 6.1 Commissioning
 - 6.2 Shutting down
 - 6.3 Maintenance
 - 6.4 Putting back into operating
- 7.0 Troubleshooting**
 - 7.1 Detection of defects
 - 7.2 Troubleshooting plan
- 8.0 Dismantling of the Valve**
 - 8.1 Replacement of wear parts
- 9.0 Warranty**
- 10.0 Explanations on Codes and Directives**
- 11.0 Drawing**
 - 11.1 Sectional drawing
 - 11.2 View drawing
 - 11.3 Control valve
 - 11.4 List of parts
- 12.0 Declaration of Conformity**

1.0 General Remarks

This operating manual includes instructions to assemble and operate the valve in the prescribed and safe way. **Additionally and accordance with the solenoid drive of the control valve (805), the relevant manufacturer's operating instructions must be taken into consideration.**

If any difficulties appear that can't be solved by means of the operating manual, further information may be demanded from the manufacturer.

If the solenoids are used abroad of the FRG, the operator and/or the person who is responsible for the plant concept must take care that the valid national rules are met

The use of these operating instructions suppose the qualification of the user according to paragraph 2.3 "qualified staff".

The operating staff must be trained in accordance with the operating instructions. The operating manual must always be available at the location where used.

1.1 Valve data

Manufacturer:

UNI Geräte E. Mangelmann
Elektrotechnische Fabrik GmbH
Holtumsweg 13
D-47652 Weeze
Telefon: +49 (0) 2837/9134-0
Fax: +49 (0) 2837/1444
E-Mail: info@uni-geraete.de
Homepage: www.uni-geraete.de

Designation

Directly functioning, currentless opened, spring safety shut off valve with pneumatic drive.

Test basis:

DIN EN 13611; DIN EN 16678
DIN EN ISO 23553-1

Type	Working pressure	Ambient temperature	Medium	Medium temperature	Test pressure (*) PT
10-4-EPVF..N.R..	10 bar	-10°C to + 60°C	Steam	-10°C to +160°C	PT 16
15-4-EPVF..(N).R.(Ü).	15 bar	-10°C to + 60°C	Steam	-10°C to +300°C	PT 40
40-4-EPVF..R..	40 bar	-10°C to + 60°C	Water, Fuel oil, synthesis gas, methanol, gas, hot air, steam, Thermal oil	-10°C to +200°C -10°C to +250°C -10°C to +300°C	PT 40
50-4-EPVF..N.Ü.R.(#)	50 bar	-10°C to + 60°C	Natural gas	-10°C to +230°C	PT 100
55-4-EPVF..N.Ü.R.(#)	55 bar	-10°C to + 60°C	Natural gas	-10°C to +230°C	PT 100

(*) Test pressure to perform leakage test "NO FUNCTION TEST"

Fitting position:

with vertical or horizontal drive.

(#) with vertical drive

Switching cycles:

500 cycles/h

EPVF-R with flange connection measures acc. to DIN EN 1092-2 / ANSI

Flange DN	PN	15	20	25	32	40	50	65	80
Flange ANSI	ANSI	(5N) 1/2"	(7N) 3/4"	(10N) 1"	(12N) 1 1/4"	(15N) 1 1/2"	(20N) 2"	(25N) 2 1/2"	(30N) 3"
10-4-EPVF...N.R..	16	-	-	-	-	-	O	-	-
15-4-EPVF...N.Ü.R..	40	-	-	-	-	-	-	-	O
40-4-EPVF...N.R..	40	O	O	O	-	-	-	-	-
50-4-EPVF...N.Ü.R..	600lbs	O	-	-	-	-	-	-	-
55-4-EPVF...N.Ü.R..	600lbs	O	-	-	-	-	-	-	-

X Type test acc. , O Acceptance test certificate 3.2 possible, - not available,

EPVF-R with threaded connection dimension at DIN ISO 228-1

Connection G	1/4" (2)	3/8 (3)	1/2 (5)	3/4 (7)	1 (10)	1 1/4 (12)	1 1/2 (15)	2 (20)
15-4-EPVF...R..	-	-	-	O	-	-	-	-

Control medium: Air, nitrogen -20°C to + 60°C
Control pressure: Min. –control pressure, second number on the type plate
 Max. –control pressure 4-10bar
Electric connection control valve: Notice instructions on type plate of control valve.

1.2 Application

The UNI- Geräte pneumatic valve EPVF-R are used as automatic safety shut-off valves for protection, limitation, shut-off and release of gas supply at main stops, in front of gas burners or used in oil installations on steam boilers

The valves are suitable for natural gases and for neutral gases or for fuel oil EL and M and other liquids having a viscosity rate up to 75mm²/s.

If used in other cases, the operator must carefully check if construction/design of valve, accessories and materials are suitable for the new application. The range of application is subject to the responsibility of the plant planner. The service life of the valve is 20 years.

2.0 Danger Notices

2.1 Safety terms

The signal terms DANGER, CAUTION und NOTICE are used in this operating manual in case of notices concerning special dangers, or for unusual information, requiring a special marking.



DANGER! means that in case of non-observance there is danger to life and/or considerable damage.



CAUTION! means that in case of non-observance there is danger of injury and/or damage.



NOTICE! means that attention is drawn to technical correlations/connections.

Observance of other, not especially marked notices concerning transport, assembly, operation and maintenance and other data (in the operating manual, product documentation and at the unit itself) is also essential, in order to avoid disturbances that might affect direct or indirect damage to property or injury to persons.

2.2 Safety notice

Non observance of safety instructions can lead to loss of any claim for damages.

Non observance can lead to the following mentioned dangers:

- Failure of important functions of the valve/plant
- Endangering of persons by electrical or mechanical influences.
- Protection against accidental contact for moving parts may not be removed as long as the valve is in operation.
- Leakage of dangerous media (e.g. explosive, toxic, hot) must be removed in the way that there is no danger for persons or environment. Laws and regulations must be observed.

2.3 Qualified staff

These are persons who are familiar with erection, assembly, starting, operation and maintenance of the product and who have special qualifications acc. to their activities and functions, e.g.:

- Instruction and obligation to carry out and meet all regional and in-house orders and requirements.
- Education or instruction according to the safety engineering standards in use and maintenance of adequate safety and working protection equipment.
- Training in first aid.

2.4 Unauthorized modification and spare part production

Modification or changes of the valve are only allowed after agreement of the manufacturer. Original drawings and accessories authorized by the manufacturer are for safety purposes. The use of other parts or unauthorized changes at the valve by third persons may cancel and abolish the manufacturer's liability for resulting consequences.

2.5 Unauthorized operation

Operational reliability of the delivered valve is only guaranteed in case of determined use in accordance to paragraph 1 of the operating manual. **The application limits mentioned on the type sign may on no account be exceeded.**

2.6 Safety information for the use in explosion-prone areas guideline 2014/34/EU

- The temperature of the medium must not exceed the respective temperature class, and respectively, the respective maximum permitted medium temperature as per operation guideline.
- If the valve is heated (e.g. heating jacket), care must be taken, that the specified temperature class is kept in the time.
- The valve must be connected to the ground.
In the case most simple this can be realized via pipe screws by means of tooth disc.
Otherwise the connection to the ground must be implemented by other measures e.g. cable links.
- Control valves, electrical and electrical/mechanical drives as well as sensors must undergo a separate conformity check as per ATEX. In doing so the respective safety and explosion protection information in the operation instructions are to taken into special consideration.
- Any modifications whatsoever to the valve are not allowed. The ATEX approval is void with immediate effect if the valve is modified without prior authorisation (even including painting).
- UNI- Geräte GmbH must be consulted before any modifications are made.

Furthermore we point out the guideline ATEX 118a, which include the minimum regulations for the improvement of the health-related situation and the safety of the employees, who might be jeopardized by an explosive atmosphere.

2.7 Safety information regarding guideline 2014/68/EU attachment I



Danger!

UNI valves are not an accessory with a safety function as defined in the PED 2014/68 / EU Article 2 (4) and Article 4 (1) (d) by category IV Use or classify!

3.0 Handling

3.1 Transport

For any transport works, the generally recognised technical rules and standards as well as rules for prevention of accidents must be observed.

In case of transport, storage and stopping, the flange protection caps must be mounted at both valve flanges.

The goods to be transported must be carefully treated. During transport, the valve must be protected against strokes, impacts or vibration. The coat of lacquer may not be damaged. Transport temperature is -20°C up to $+60^{\circ}\text{C}$.

Never transport the valve at pneumatic drive piping/ tubing or components. Transport the valve at provided transport angles (256) from KA120 or ring nut (926) from KA160.

Transport the valve in a box or on a pallet with soft base and it smoothly on even floor. **Never put valve on the piping/ tubing or its components.**

The goods must be checked on completeness and transport damage. See also section 9.0

3.2 Storage

If the valve is not installed immediately after delivery, it must be stored properly.

- Storage temperature -20°C up to $+60^{\circ}\text{C}$, dry and clean.
- The lacquer protects against corrosion in neutral dry atmosphere. Do not damage colour.
- In humid rooms, a drying agent or a heating resp. is necessary because of condensation of water.

Requirements according to DIN 7716 (products made of caoutchouc and rubber) must be met.

3.3 Handling before mounting

- In case of valve with protection caps, they must be removed before being mounted!
- Protect against atmospheric influences such as humidity.
- Appropriate treatment protects against damage.

4.0 Product Description

The UNI- Geräte pneumatic valves of the series EPVF-R are directly controlled, currentless opened shut-off valve with fast shut-off function with pneumatic drive.

The drive is actuated by a 3/2 way control valve with solenoid drive, type 10-EVD 2 or 10-EVD 2/2401 resp.

The sectional drawing part 11.1 in Fig. 1 and 4 shows the valve construction.

4.1 Function

When opening the 3/2 way control valve (805) the control medium flows via the connection 3 → 2 above the drive piston (217). The control medium pushes the drive piston (217) against the pressure spring (503) and closed- via the valve spindle (205)- the valve disk (200) that is pressure impinged. The valve is close.

The valve opened in case of shut-off, failure or interruption of power energy to control valve (805). The compressed control medium in the pneumatic drive is blown-off via the control valve (805).

4.2 Technical data

Opening times: 0,8 – 2s, depends upon nominal width

Closing times: < 1s

Drive types and air consumption in standard litre (NL) per connection at 4 bar control pressure.

Flange DN	15 (5N)	20 (7N)	25 (10N)	32 (12N)	40 (15N)	50 (20N)	65 (25N)	80 (30N)
Flange ANSI	1/2"	3/4"	1"	1 1/4"	1 1/2"	2"	2 1/2"	3"
10-4-EPVF...N.R..	-	-	-	-	-	KA 120 2,5NL	-	-
15-4-EPVF...N.Ü.R..	-	-	-	-	-	-	-	250 6,5 NL
40-4-EPVF...N.R..	KA 120 2,5NL	KA 120 2,5NL	KA 120 2,5NL	-	-	-	-	-
50-4-EPVF...N.Ü.R..	KA 120 2,5NL	-	-	-	-	-	-	-
55-4-EPVF...N.Ü.R..	KA 120 2,0 NL	-	-	-	-	-	-	-

Connection G	1/2 (5)	3/4 (7)	1 (10)
15-4-EPVF...R.(Ü)..	-	KA 120 2,5NL	-

Air consumption for 10 bar, multiply control pressure table values by 2,2.

Max. valve loading by pipe power

The indicated moments may not work longer than 10s.

DN		8	10	15	20	25	32	40	50	65	80	100	125	150
Torsion	Nm	80	35	50	86	125	160	200	250 ¹⁾	325 ¹⁾	400 ¹⁾	-	-	-
Bending	Nm	35	70	105	225	340	475	610	1100	1600	2400	5000	6000	7600

¹⁾ Not valid in case of valves with flanges

Starting torque, pipe screws greased

DN		40	50	65	80	100	125	≥150
Torque	Nm	50	50	50	50	80	160	160

Starting torque, product screws and nuts greased

Screw		M6	M8	M10	M12	M16	M20	M24
Torque	Nm	5	11	22	39	70	110	150

4.3 Marking

The type sign on the pneumatic drive has the following information:

- Fabricator
- Valve type, nominal width, pressure and temperature indication, fitting position
- Year of construction/ production no.
- TÜV report-no.
- CE-sign and no. of relevant location to 2014/34/EU
- Fluid group and test pressure PT to 2014/34/EU
- Pneumatic drive type KA120 or KA250
- Control medium, p_{\min} and p_{\max} for control medium.

Refer also to section 10.0.

5.0 Installation

5.1 Warning of dangers during installation, operation and maintenance



DANGER!

Safe operation of the valve can only be guaranteed if it is installed, commissioned and maintained by qualified personnel (see point 2.3 "Qualified staff") correctly and in observance of the warnings in this operating manual. Apart from that, the operation safety order and the qualified use of tools and protection equipment must be guaranteed. The operating instructions for the valve must be observed during all work on or with the valve. Failure to observe these instructions may result in injury or in damage to the valve or other installations.

When the valve is used as a final sealing element, a safety precaution e.g. blanking disc, blind flange, etc., in accordance with the code of practice of the German Technical and Scientific Association for Gas and Water (DVGW) is recommended during all repair work.

5.2 Installation

Apart from the general installation guidelines, the following points should be observed:



NOTICE!

- Remove the flange covers.
- The inside of the valve and the pipeline must be free from foreign particles.
- Observe the installation position in relation to the flow direction, see markings on the valve.
- Centre gaskets between the flanges.
- The connecting flanges must be aligned.
- Ensure that none of the components is strained during installation.
- The valve must not be used as a fixed point; it is supported by the pipework system.
- Protect valves from soiling, particularly during construction work.
- Thermal expansion of the pipework must be equalized using compensators.

The valve can be installed with vertical or horizontal pneumatic drive. The solenoid drive of the control valve should preferably be installed with vertical drive. The control air must be connected at connection 3. We recommend an air filter in front of the control valve. Mesh size 40 μm .



NOTICE!

Please observe the control valve operating instructions.

6.0 Operation



DANGER!

Before commissioning a new installation or before starting up an installation again after repairs or modifications, ensure:

- The proper completion of all installation and assembly work!
- Commissioning only by “qualified staff” (see point 2.3).
- Installation or repair of existing guards and protection equipment.

6.1 Commissioning

- Before commissioning, check the data on material, pressure, temperature and flow direction with the layout plan of the pipework system.
- Depending on the field of application, the local regulations have to be observed, e.g. the operation safety order.
- Residues in the pipework and the valve (dirt, weld beads, etc.) will inevitably result in leaks.
- Leakage inspection of the installed valve.

6.2 Shutting down

- Depending on the field of application, the local regulations have to be observed, e.g. the operation safety order.

6.3 Maintenance

pneumatic valves have to be checked at regular intervals for proper function and internal leak tightness. The intervals for regular inspections have to be defined by the operator according to the operating conditions. UNI-Geräte recommends an internal visual inspection once a year and an overhaul of the valve after 2 years or after the following number of switching cycles at the latest:

Application temperature	≤ DN 25	≤ DN 80	≤ DN 150	> DN 150
≤ 25°C	150 000	75 000	25 000	20 000
> 25°C	50 000	25 000	25 000	5 000

Repair or maintenance works at the manufacturing company (UNI- Geräte)

- Valves and fittings must be delivered clean and free from substances which are harmful to health or to the environment.

UNI-Geräte prescribes the following maintenance intervals for valves with SIL requirements:

The safety requirements with regard to the maintenance intervals to be adhered are described in the **SIL manual** of the type series and must be complied with.

6.4 Putting back into operation

When putting a valve back into operation, ensure that all the necessary steps described in section 5.2 (Installation) and section 6.1 (Commissioning) are repeated.

7.0 Troubleshooting

7.1 Detection of defects



DANGER!

Be sure to observe the safety instructions during troubleshooting.

If the malfunctions cannot be remedied using the following “**Troubleshooting plan (7.2)**” please contact the manufacturer.

In the event of faults in the function or operating behaviour of the valve, check whether the installation work was carried out and completed as described in this operating manual. Depending on the field of application, the operation safety order must be observed.

Check the data on material, pressure, temperature, voltage and flow direction with the layout plan of the pipework system. In addition, check whether the operating conditions correspond to the technical data in the data sheet or on the rating plate.

7.2 Troubleshooting plan

Malfunction	Possible causes	Remedy
No flow	Pneumatic drive does not open	Switch off control valve (805) Clean sound absorber (600)
	Protective caps were not removed	Remove protective caps
Low flow rate	Obstruction in the pipe system	Check pipe system
Valve leaking at seat, no internal tightness	Valve disc sealing (400) or valve seat (100) damaged by external particles	See section 8 or replace valve
No external tightness	Gaskets damaged	See section 8 or replace valve
Valve closes too slowly	Control pressure too low	Check control pressure
	Reduced conductor cross sections	Replace folded control lines
Valve opens too slowly	Dirt in control line	Clean sound absorber (600)
		Clean vent line
Valve does not close	Control valve does not open	Check, if residual voltage is aligned
	Dirt in control line	If necessary, clean filter in control line
	Reduced conductor cross sections	Replace folded control lines
Flange fracture (valve/ pipework)	Screws not tightened uniformly, mating flanges not aligned	Align pipework. Install new valve



NOTICE!

Observe section 9.0 before all installation and repair work!

Observe section 6.4 when putting the valve back into operation!

8.0 Dismantling of the Valve

In addition to the general installation guidelines and the operation safety order, the following points must also be observed:



DANGER!

- Depressurised pipework system
- Cooled medium
- Emptied installation
- Vent pipework systems containing corrosive, inflammable, aggressive or toxic media
- Have dismantling work carried out only by qualified staff (see point 2.3)

8.1 Replacement of wear parts

Shut down the valve as described in section 6.2.

Switch off control valve (805) and disassemble the control line from pneumatic drive.

Remove attachments (limit switch mounting).

Fig.1 Flange version 10/40-4-EPVF ...N.R...

Loosen hexagon screw (900/2) with lock washer (905/3) and remove spring cap (112).



DANGER!

Dismantling the spring disc (216).

Spring disc (216) with drive piston (217) is under spring tension. By depressing the spring disc (216) and loosen the hex. nut (901/2) with lock washer (905/4), the pressure spring (503/1) are relaxed.

Remove pressure spring (503/1) with sealing piece (226), drive piston (217), spring disc (216) and pneumatic cylinder (111).

Release safety bolt (902/2) with SL-retainer (949). Remove valve spindle (205/1).

Drive spring dowel sleeve (943/2) out of the expansion bellows (504).

Loosen cylinder screw (910/2) with lock washer (905/2) and remove spacer (110).

Loosen cylinder screw (910/1) with lock washer (905/1) and remove housing flange (108/1).

Take valve disk complete (200) with expansion bellows complete (504) and distort protection (227) out of valve chamber (100).

Fig.2 Flange version 15-4-EPVF 30NÜ.R...Bn...

Replace the complete pneumatic valve

Fig.3 Flange version 50-4-EPVF ...N.Ü.R...

Loosen hex. head screw (900/3) with Nordlock washer (948/3) and remove spring cap (112).



DANGER!

Dismantling the spring disc (216).

Spring disc (216) with drive piston (217) is under spring tension. By depressing the spring disc (216) and loosen the hex. nut (901/1) with lock washer (905/1), the pressure spring (503/1) are relaxed.

Remove pressure spring (503/1) with sealing piece (226), drive piston (217), spring disc (216) and pneumatic cylinder (111).

Release safety bolt (902/2) with SL-retainer (949). Remove valve spindle (205/1). Drive spring dowel sleeve (943/1) out of the expansion bellows (504). Loosen cylinder screw (910/1) with Nordlock washer (948/2) and remove spacer (110). Take valve disk complete (200) with expansion bellows complete (504), distance ring (509) and distort protection (227) out of valve chamber (100). Loosen hexagon screw (900/1) with Nordlock washer (948/1) and remove housing flange (108/1).

Fig.4 Flange version 55-4-EPVF ...N.Ü.R...

Limit switch (803) off power supply
Loosen cylinder screw (910/2) with Nordlock washer (948/2) and remove housing flange (108/1).



DANGER!

Dismantling the spring disc (216).

Spring disc (216) with drive piston (217) is under spring tension. By depressing the spring disc (216) and loosen the hex. nut (901/2) with lock washer (905), the pressure spring (503) are relaxed.

Remove pressure spring (503/1) with sealing piece (226), drive piston (217), spring disc (216) and pneumatic cylinder (111). Release safety bolt (902/2) with SL-retainer (949). Remove valve spindle (205/1). Drive spring dowel sleeve (943) out of the expansion bellows (504). Loosen and remove cylinder screw (910/1) with Nordlock washer (948/1). Remove spacer (110) with limit switch console (512) and limit switch (803). Take valve disk complete (200) with expansion bellows complete (504), distance ring (509) and distort protection (227) out of valve chamber (100).

Fig.5 Thread version 15-4-EPVF 7R.(Ü)...

Replace the complete pneumatic valve

In case of damage to the valve seat, replace the whole pneumatic valve.
If the sealing element becomes damaged the spare parts kit should be used.

All parts marked as spare parts are to be replaced.

Install the valve in reverse order.

The lip rings (404) are to be lubricated with lubricant Staburags N32 or equivalent (DVGW-permission).

Lubricate the pneumatic cylinder (111) within they are of the drive piston (217) with lubricant Staburags NBU 30.



DANGER!

For special application such as for oxygen use only the approved Lubricants and appropriate sealing materials (Bam-approval).



CAUTION!

Install wear parts carefully and properly and do not damage them during assembly.

Examine the valve for internal and external leaks and finally carry out a function test.

9.0 Warranty

Scope and period of the warranty is specified in the edition of the "General Terms of Business of the UNI-Geräte E. Mangelmann Elektrotechnische Fabrik GmbH" valid at the time of delivery or else in the purchase agreement.

We warranty that the valve is free from faults in line with the state of the art and for the confirmed field of application.

No warranty claims will be accepted for damage resulting from improper use or failure to observe these operating and installation instructions, the statutory accident prevention regulations, the EN, DIN and VDE standards and other codes and regulations.

Warranty claims will also not be accepted for damage occurring during operation due to operating conditions deviating from those specified in the data sheet or in other agreements.

Justified complaints will be remedied by reworking by us or specialist companies authorized by us.

Claims going beyond the scope of the warranty will not be accepted. The customer shall have no right to the supply of a replacement valve.

Maintenance work, installation of parts from other manufacturers, any modifications to the design and natural wear are not covered by the warranty.

Transport damage must be reported not to us but **without delay** to your responsible goods handling company, the railway company or the shipping agent as otherwise all claims for damages against these companies will be voided.

10.0 Explanation on Codes and Directives


The Commission of the European Union has laid down common directives for the free trading of goods within the Union specifying minimum requirements for safety and health protection. The CE symbol confirms that products comply with the EU directives, i.e. in conformity with the relevant, in particular harmonised standards. Directive 2014/68/EU is relevant for the gas pneumatic valve (mechanical part).

Notes on Directive 2014/68/EU (Pressure Equipment Directive, DGRL):

It has been confirmed that the quality assurance in design control, manufacture and final acceptance of the manufacturer, UNI-Geräte E. Mangelmann Elektrotechnische Fabrik GmbH, satisfy the requirements of 2014/68/EU Article 14 Module H. The pneumatic valves comply with the fundamental requirements of Directive 2014/68/EU. Valves in according to Article 1 Paragraph 2,f,v or Article 4 paragraph 3 are not allowed to have the CE Mark in according to Article 18.

11.0 Drawing

11.1 Fig.1 Flange design 10/40-4-EPVF...N.R...



..... = Spare part kit

X = option limit switch mounting

Fig.2 Flange design 15-4-EPVF 30NÜ.R.Bn...





Fig.3 Flange design 50-4-EPVF 5NÜ.R...



..... = Spare part kit

X = option limit switch mounting

Fig.4 Flange design 55-4-EPVF 5NÜ.R...





Fig.5 Thread design 15-4-EPVF 7R.(Ü)...



11.2 Projection

Fig.1 10/40-4-EPVF...N.R....




Fig.2 15-4-EPVF 30NÜ.R.Bn..




Fig.3 50-4-EPVF 5NÜ.R....




Fig.4 55-4-EPVF 5N.Ü.R....






Fig.5 15-4-EPVF ...R.(Ü)...



11.3 Control valve



Connection 1 = Ventilation
Connection 2 = Drive
Connection 3 = Control air

11.4 List of parts

<h1 style="margin: 0;">Stückliste</h1> <p style="margin: 0; color: #4F81BD;">list of parts</p>	 <small>elektrotechnische fabrik gmbh</small>
BTA Nummer 220.100.219 DE / 220.100.220 EN	
<i>Instruction No.</i> 220.100.219 DE / 220.100.220 EN	

Pos/Item	116.001.452	116.002.241	116.001.419	116.001.566	116.002.548	DEU	ENG
						Benennung DEUTSCH	Parts description ENGLISH
1	100	1	1	1	1	Ventilgehäuse	valve chamber
2	101				1	Gehäusemutter	housing nut
3	108 / 1	1	1	1	1	Gehäuseflansch	housing flange
4	108 / 2	1	1	1	1	Gehäuseflansch	housing flange
5	108 / 3		1			Gehäuseflansch	housing flange
6	108 / 4		1			Gehäuseflansch	housing flange
7	108 / 5		1			Gehäuseflansch	housing flange
8	109		1			Gehäusezylinder	housing cylinder
9	110	1		1	1	Distanzstück	spacer
10	111	1	1	1	1	Pneumatikzylinder	pneumatic cylinder
11	112	1		1	1	Federdom	spring cap
12	118		4			Stützen	supports
13	200	1	1	1	1	Ventilteller	valve disk
14	201	1		1	1	Tellerscheibe	disc plate
15	204		1		1	Federführung	spring guide pin
16	205 / 1	1	1	1	1	Ventilspindel	valve spindle
17	205 / 2		1		1	Ventilspindel	valve spindle
18	206		1			Führungsring	guide ring
19	208	1	1	1	1	Schlagdämpfung	sound insulation
20	212				1	Spindelführung	spindle guide
21	212 / 1	1	1	1		Spindelführung	spindle guide
22	212 / 2		1			Spindelführung	spindle guide
23	213	1			1	Gewinding	ring nut
24	216	1		1	1	Federteller	spring disc
25	217	1	1	1	1	Antriebskolben	drive piston
26	218		1			zweiteiliger Ring	two-piece ring
27	219		1			Spindelmutter	spindle nut
28	226	1		1	1	Dichtstück	sealing piece
29	227	1	1	1	1	Verdrehschutz	Distort protection
30	259		1		1	Scheibe (Fertigungsteil)	disc (production piece)
31	400	1		1	1	Ventiltellerdichtung	valve disk sealing
32	402 / 1	1	1	3	2	Flachdichtung	gasket
33	402 / 2		1		1	Flachdichtung	gasket
34	403 / 1	1	2	1	1	O-Ring	o-ring
35	403 / 2	1	1	1	2	O-Ring	o-ring
36	403 / 3	1	1	1	1	O-Ring	o-ring
37	403 / 4	1		1		O-Ring	o-ring
38	403 / 5	1#		1#		O-Ring	o-ring
39	404 / 1	1	1	1	2	Lippenring	lip-ring
40	404 / 2	1#	1	1#		Lippenring	lip-ring
41	406		2		2	Packung	packing
42	503				1	Druckfeder	pressure spring
43	503 / 1	1	1	1	1	Druckfeder	pressure spring
44	503 / 2		1			Druckfeder	pressure spring
45	504	1	1	1	1	Faltenbalg	expansion bellows
46	505		1	4		Schutzkappe	protective cap

Stückliste

list of parts



BTA Nummer 220.100.219 DE / 220.100.220 EN

Instruction No. 220.100.219 DE / 220.100.220 EN

Pos/Item	116.001.452	116.002.241	116.001.419	116.001.566	116.002.548	DEU	ENG
						Benennung DEUTSCH	Parts description ENGLISH
47	507	1	1	1	1	Faltenbalgstück	bellow piece
48	509		1	1		Distanzring	distance ring
49	512			2		Endschalterkonsole	limit switch console
50	512 / 1	1				Endschalterkonsole	limit switch console
51	512 / 2	1				Endschalterkonsole	limit switch console
52	513	1	1			Endschalterbetätigung	switch actuator
53	600 / 1	1				Schalldämpfer	sound absorber
54	600 / 2	1				Schalldämpfer	sound absorber
55	601	1				Schnellentlüfter	quick-venting mechanism
56	803	2	2			Endschalter	limit switch
57	805	1				Steuerventil	control valve
58	900			4		Sechskantschraube	hexagon head screw
59	900 / 1	4	4	4		Sechskantschraube	hexagon head screw
60	900 / 2	4	4	4		Sechskantschraube	hexagon head screw
61	900 / 3	4	4			Sechskantschraube	hexagon head screw
62	900 / 4	4				Sechskantschraube	hexagon head screw
63	900 / 5	4				Sechskantschraube	hexagon head screw
64	901 / 1	1	1	1	1	Sechskantmutter	hexagon nut
65	901 / 2	1	4	1		Sechskantmutter	hexagon nut
66	901 / 3	1				Sechskantmutter	hexagon nut
67	901 / 4	4				Sechskantmutter	hexagon nut
68	901	1				Sechskantmutter	hexagon nut
69	902	1				Bolzen	bolt
70	902 / 1	1	1	1	1	Bolzen	bolt
71	902 / 2	1	1	1		Bolzen	bolt
72	903	1			1	Kerbstift	grooved dowel pin
73	904				1	Verschlußschraube	screwed plug
74	905			1		Federring	lock washer
75	905 / 1	4	4	1	4	Federring	lock washer
76	905 / 2	4	16		8	Federring	lock washer
77	905 / 3	8	4		1	Federring	lock washer
78	905 / 4	1	4			Federring	lock washer
79	905 / 5	1				Federring	lock washer
80	905 / 6	4				Federring	lock washer
81	906	4				Scheibe	washer
82	910 / 1	4	8	4	4	Zylinderschraube	cylinder head screw
83	910 / 2	4	4		4	Zylinderschraube	cylinder head screw
84	910 / 3	1				Zylinderschraube	cylinder head screw
85	912	1	1	1		Splint	split-pin
86	913	1				Gerade Einschraubverschraubung	Linear threaded screw connection
87	914 / 1	1				Gerader Aufsteckstutzen	Linear put on adapter
88	914 / 2	1				Gerader Aufsteckstutzen	Linear put on adapter
89	915	1				Ringmutter (Nennweitenabhängig)	ring nut (depending on dimension)
90	923	1				Gewindestift	setscrew
91	926	2				Spannstift	spring dowel sleeve

<h1 style="margin: 0;">Stückliste</h1> <p style="margin: 0; color: #4F81BD;">list of parts</p>	
BTA Nummer 220.100.219 DE / 220.100.220 EN	
<i>Instruction No. 220.100.219 DE / 220.100.220 EN</i>	

Pos/Item	116.001.452	116.002.241	116.001.419	116.001.566	116.002.548	DEU	ENG
						Benennung DEUTSCH	Parts description ENGLISH
92	941	2	1	1		Spannstift	spring dowel sleeve
93	943			1		Spannstift	spring dowel sleeve
94	943 / 1	1	1	1	1	Spannstift - Schwere Ausführung	spring dowel sleeve - solid version
95	943 / 2	1	1		1	Spannstift - Schwere Ausführung	spring dowel sleeve - solid version
96	948 / 1		4	4		Nordlockscheibe	Nordlock washer
97	948 / 2		4	8		Nordlockscheibe	Nordlock washer
98	948 / 3		4			Nordlockscheibe	Nordlock washer
99	948 / 4					Nordlockscheibe	Nordlock washer
100	948 / 5		4			Nordlockscheibe	Nordlock washer
101	949	1	1	1	1	SL-Sicherung	SL-retainer
102	950	1	1	1	1	Kugel	ball
103	983				1	Entlüftungsstopfen	exhaust plug
104	1204 / 1		1			Zylinderstift	cylinder pin
105	1204 / 2		1			Zylinderstift	cylinder pin

Spare parts

Type	Fig.	Spare parts
10/40-4-EPVF...N.R...	Fig.1	Spare part kit
50-4-EPVF...N.Ü.R...	Fig.3	Spare part kit
55-4-EPVF...N.Ü.R...	Fig.4	Spare part kit

Dimension Flange design

Series	DN / Class	A	ANSI	B	B`	ØC	D	E
10-4-EPVF...N.R..	50	230	2"	517	637	170	403	-
15-4-EPVF...N.Ü.R.Bn..	80	310	3"	774	924	315	755	-
40-4-EPVF...N.R..	15	130	1/2"	502	622	170	383	-
	20	150	3/4"	502	622	170	383	-
	25	160	1"	502	622	170	383	-
50-4-EPVF...N.Ü.R..	600 lbs	203	1/2"	482	602	170	368	82
55-4-EPVF...N.Ü.R..	600 lbs	203	1/2"	409	529	170	393	-

Dimension Thread design

Series	G	A	B	B`	ØC	D	E
15-4-EPVF...R.(Ü)...	3/4	105	517	637	170	273	60

A = Dimension at DIN (resp. flanges ANSI and dimension DIN or flanges and dimension at DIN)

B` = Dimension for removing the drive piston

12.0 Declaration of Conformity

UNI-Geräte E. Mangelmann
Elektrotechnische Fabrik GmbH
Holtumsweg 13
D – 47652 Weeze



EU Konformitätserklärung Declaration of Conformity

Produkt <i>Product</i>	Sicherheitsabsperrentil <i>Safety shut-off valve</i>
Handelsbezeichnung <i>Trade Mark</i>	Pneumatikventil <i>Pneumatic Valve</i>
Baureihe / <i>Series</i>	...EPVF...R...
Nennweiten / <i>Size</i>	DN 15 – 400 ; G3/8 – G3
Fluidgruppe <i>Fluid group</i>	Brennbare Gase, FL. Gr.1 <i>Flammable gases, FL. Gr.1</i>
EU - Richtlinien <i>EU - Directives</i>	2014/68/EU Druckgeräterichtlinie / <i>Pressure Equipment Directive</i>
Konformitätsbewertungsverfahren <i>Conformity Assessment Procedure</i>	Modul H 2014/68/EU
Angewandte <i>technische Spezifikation</i> <i>Applied Technical Specification</i>	DIN EN 13611 , DIN EN 16678 , DIN EN 161 AD 2000, EN 12516, EN 12266
Überwachungsverfahren <i>Surveillance Procedure</i>	CE-0062-PED-H-UGM 001-20-DEU 2014/68/EU Modul H Bureau Veritas Services SAS 8 Cours du Triangle 92800 PUTEAUX – LA DEFENSE <i>Zertifizierungsstelle / Notified Body 0062</i>
Kennzeichnung <i>Marking</i>	CE - 0062 ¹⁾

Das Unternehmen UNI Geräte E. Mangelmann Elektrotechnische Fabrik GmbH erklärt in alleiniger Verantwortung, dass die o.a. Baureihe die grundsätzlichen Anforderungen der aufgeführten Richtlinien und Normen erfüllt.

UNI Geräte E. Mangelmann Elektrotechnische Fabrik GmbH confirms under the sole responsibility of the manufacturer, that the basic requirements of the above specified directives and standards are fulfilled.

Weeze, 14.05.2020



Geschäftsführer
Norbert Schneider
Managing Director

¹⁾ DN < 32 siehe Diagramm 6, fallen unter Artikel 4 Abs. 3 der 2014/68/EU
DN < 32 see Diagramm 6, are mentioned in article 4 § 3 of 2014/68/EU

UNI-Geräte E. Mangelmann
Elektrotechnische Fabrik GmbH
Holtumsweg 13
D – 47652 Weeze

EU Konformitätserklärung Declaration of Conformity

Produkt <i>Product</i>	Sicherheitsabsperrentil <i>Safety shut-off valve</i>
Handelsbezeichnung <i>Trade Mark</i>	Pneumatikventil <i>Pneumatic Valve</i>
Baureihe / <i>Series</i>	...EPVF...R...
Nennweiten / <i>Size</i>	DN 15 – 400 ; G3/8 – G3
Fluidgruppe <i>Fluid group</i>	Brennbare Flüssigkeiten, FL. Gr.1 <i>Flammable Liquids, FL. Gr.1</i>
EU - Richtlinien <i>EU - Directives</i>	2014/68/EU Druckgeräterichtlinie / <i>Pressure Equipment Directive</i>
Konformitätsbewertungsverfahren <i>Conformity Assessment Procedure</i>	Modul H 2014/68/EU
Angewandte technische Spezifikation <i>Applied Technical Specification</i>	DIN EN ISO 23553-1 AD 2000, EN 12516, EN 12266
Überwachungsverfahren <i>Surveillance Procedure</i>	CE-0062-PED-H-UGM 001-20-DEU 2014/68/EU Modul H Bureau Veritas Services SAS 8 Cours du Triangle 92800 PUTEAUX – LA DEFENSE <i>Zertifizierungsstelle / Notified Body 0062</i>
Kennzeichnung <i>Marking</i>	CE - 0062 ¹⁾

Das Unternehmen UNI Geräte E. Mangelmann Elektrotechnische Fabrik GmbH erklärt in alleiniger Verantwortung, dass die o.a. Baureihe die grundsätzlichen Anforderungen der aufgeführten Richtlinien und Normen erfüllt.

UNI Geräte E. Mangelmann Elektrotechnische Fabrik GmbH confirms under the sole responsibility of the manufacturer, that the basic requirements of the above specified directives and standards are fulfilled.

Weeze, 14.05.2020



Geschäftsführer
Norbert Schneider
Managing Director

¹⁾ PS*DN < 2000, siehe Diagramm 8, fallen unter Artikel 4 Abs. 3 der 2014/68/EU
*PS*DN < 2000, see diagram 8, are mentioned in article 4 § 3 of 2014/68/EU*